

Product Manual

232-Amp+

232-Amp+W

RS-232 Stereo Mixer/Amplifier

Ver 2.3 July 19, 2016



Table of Contents

Overview	3
Specifications	4
Field Setup	5
Mix/Ducking Operation	5
RS-232 Control Protocol	6
RS-232 Commands	7
Control Commands	7
Terminal Communication Commands	8
RS-232 Command Hints and Tips	8
Gating and Volume	8
Response Strings	9
Input 0 (Stereo) Status Response String (V0):	9
Input 1 Status Response String (V1):	9
Input 2 Status Response String (V2):	9
Amp Status Response String (SV):	9
Amp Gain Response String (VG):	9
RS-232 Cable Connections	10
Single 232-Amp+	10
Rack Mounting	10
RK3 AV Tool Rack Kit	10
Limited Warranty and Disclaimer	10
Limited Warranty and Disclaimer	12

Overview



232-AMP+



232-Amp+W

The Contemporary Research 232-Amp+ is a compact, programmable mixer/amplifier aimed at integration with flat-panel displays and video projectors. The versatile amp features a stereo line-level display/projector audio input and two mono aux inputs, and outputs stereo sound at 40 watts RMS. The aux inputs mix levels with the stereo input, and can be set to mute or lower other inputs when active, ideal for wireless mics and paging applications. The Class D amplifier is highly energy-efficient, using 90% of DC power for amplification, operating with very little heat, and consuming almost no power at all when quiet.

The 232-AMP+W has integrated flanges for easy surface mounting

Full RS-232 control and status is available, allowing integration with custom control systems. In addition to setting master gain and input levels, the commands can also set aux input threshold, timing, and ducking levels. Installers can adjust performance manually in the field using onboard switches and level potentiometer.


The new V2.2 firmware adds the ability to change gain with the Level pot, set Mono 1 and 2 to a mixer mode with no ducking. As a result, many applications can be set up with only a screwdriver.

- Drives stereo speakers at 16 watts RMS – 32W (16W per channel) @ 8 ohms, 40W (20W per channel) @ 4 ohms
- Mixes one stereo line input with two mono inputs, mono inputs can "duck" other inputs, with programmable ducking on/off, threshold, timing, and mute levels
- Features programmable input levels and volume (volume affects stereo input, mono inputs are fixed)
- Offers field adjustment with onboard DIP switches and level potentiometer
- UL 2043 plenum rated
- 2-way RS-232 control for control systems and wall panels
- Responds to Sharp TV or CR IR remote for Volume Up, Down, and Mute
- Connects speakers and control from captive screw terminals
- Includes 3 A 18 VDC power supply (domestic only), and captive-screw control terminals
- IR-RXC Remote Sensor or compatible IR sensor (carrier can be on or off)

Firmware


- Version 1.7 – Fixes bug where a bump command did not affect Line input volume
- Version 1.5 – Improves ducking performance, Mono 1 and 2 will trigger amp on as well as Line
- Version 1.8 - Adds a Mute On/Off to inputs
- Version 1.9 – Helps to reduce noise in some applications, requires a board modifications in older 232-AMP and AMP+ units.
- Version 2.1 - The V-series commands such as mute only affect the stereo input, not 1 and 2.
- Version 2.2 – Adds more setup options for switches and pot
- Version 2.3 – Adds IR Volume and Mute control

Specifications



Physical	<p>232-Amp+: 5.5" [140mm] wide x 1.1" [28mm] height x 3.5" [86mm] deep 7.7" [196mm] wide with SMA bracket</p> <p>232-Amp+W: 7.7" [196mm] W x 1.1" [28mm] H x 3.5" [86mm] D</p> <p>Weight: 8 oz [226g]</p> <p>Enclosure: All aluminum with durable black powder coat paint</p> <p>232-Amp+ Mounting: Optional SMA Brackets attach 232-Amp+ to CR tuner or surface, mount alongside CR tuner in RK-1, rack-mount in RK3 rack kit</p> <p>232-Amp+W Mounting: Integrated flanges for surface mounting</p> <p>Standards: RoHS compliant and energy-efficiency meets new California standards, UL 2043 plenum rated</p>
Audio	<p>Amplifier Class D, highly energy-efficient, operates with very little heat</p> <p>Inputs</p> <p>Stereo: Stereo 3.5 mm jack, unbalanced, 7.5K ohms impedance, 1.4 V RMS max Programmable input level</p> <p>Inputs 1 and 2: Two Mono 3.5 mm jack, unbalanced, 7.5K ohms, 1.4 V RMS max Programmable for input level and ducking gating, timing, and mute levels</p> <p>Gain Potentiometer: Adjusts volume in normal mode, sets other levels in program mode</p> <p>DIP switches: Located on bottom of 232-Amp+ interact with Gain for field setup</p> <p>Operation: Master volume commands affects Input 1 only</p> <p>Output</p> <p>Speakers: 5-pin captive-screw terminal for stereo speaker installation, 8 or 4 ohm</p> <p>Watts @ 18 VDC: 32W RMS (16W per channel) @ 8 ohms 40W RMS (20W per channel) @ 4 ohms</p> <p>Watts @ 12 VDC: 16W RMS (8W per channel) @ 8 ohms 30W RMS (15W per channel) @ 4 ohms</p> <p>Gain: Added gain 20 dB (default), programmable to 26, 32, or 36 dB</p> <p>THD + Noise: 0.25% typical</p> <p>Response: +/-1 dB, 20 Hz to 20 kHz, 1 watt output</p> <p>Crosstalk: >65 dB @ 1 kHz, >58 dB @ 20 kHz</p> <p>Protection: Thermal and short-circuit protected, auto-recovery</p>
Control	<p>5-pin captive-screw terminal</p> <p>RS-232: GND, TX and RX, also GND for IR sensor</p> <p>Signal (Sig): IR Input, Sharp TV or CR IR codes, carrier can be on or off</p> <p>Power (V+): 12-18 VDC output to IR sensor</p> <p>DIP switches on bottom of 232-Amp+ interact with Gain for field setup</p>
Power	<p>Power LED: Green LED flashes when DC power is active, slow flash in standby mode</p> <p>Power In: 5-pin captive-screw terminal</p> <p>3 A maximum @ 18 VDC, 11.5 to 19 VDC, 18 VDC typical (may be unregulated)</p>
Includes	<p>18 VDC 3 A digital switching power supply (North American shipments only)</p> <p>Two 5-pin captive screw terminals</p>
Options	<p>SMA Surface Mount for AV Tools</p> <p>RK-3 Rack Mount Kit for mounting up to 3 AV Tools across in 19" rack, 1 RU</p> <p>IR-RXC Remote Sensor (can operate at 12-18V, check with others for voltage range)</p>

Field Setup



All the parameters can be programmed via RS-232, but many can be set using the DIP switch on the bottom of the case and the Level potentiometer on the front panel

Amp Settings

- Switches 1 and 2 Off = Stereo level, use Level pot to adjust level
- Switches 1 and 2 On = Amp gain, use Level pot to change
- Switch 1 On, Switch 2 off = Mono 1, use Level pot to adjust level
- Switch 1 Off, Switch 2 On = Mono 2 level, use Level pot to adjust level
- Switch 4 On = Mono 1 Mix mode, no ducking, reverts when switch is off
- Switch 5 On = Mono 2 Mix mode, no ducking reverts when switch is off
- Switch 8 = RS-232 baud rate, Off for 9600, On for 1200
- All Switches On = Reset to factory default

Status LED

The green LED will stay lit when the unit is powered and the output is active. A slow flash on the LED indicates the amplifier is in standby mode (no audio input level, timed out to standby).

Mix/Ducking Operation

Inputs 1 and 2 can serve as mix or ducking inputs. Ducking means that, when audio on one input rises about a trigger level, it will mute the other inputs. The 232-Amp+ allows you to set several parameters for automatic ducking operation for both inputs.

- Volume – This sets the gain level for the input.
- Gate Threshold – Set the input audio level that triggers ducking .
- Gate Hold Time – Sets how long the gate will be held open before checking the Gate level.
- Ducking Level – Sets the volume level for the stereo input during ducking – the other mono input will be muted.

Input 1 always has priority – use this input for audio from a paging system.

RS-232 Control Protocol

Overview

The 232-Amp+ full duplex RS-232 enables a system programmer to control all functions as well as monitor status. All commands are sent as ASCII strings. No delays between characters or commands are required, as data is interrupt driven and buffered.

There are four status strings for the 232-Amp, three for each input channel and one for general Amp status.

One 232-Amp+ may be daisy-chained together with a CR 232-series tuner from a single RS-232 port. The 232-Amp+ is pre-set to Unit 1, and the tuner would be set to Unit 2.

Communications parameters (Front Panel Mode 1) are 300 to 19200 baud, 8 data bits, No parity, and 1 stop bit. Factory default is 9600 baud, Unit#1.

All settings are saved to NVRAM in the 232-Amp.

The tuner will accept non-standard RS-232 control such as voltage that swings from 0 to +5 VDC, commonly found when IR ports are used to send RS-232 commands.

General protocol specifications

Characters in command strings to the 232-Amp+ are common ASCII keyboard characters.

Command strings sent to the 232-Amp+ begin with the ASCII > (greater than symbol) as an 'Attention' character and end with carriage return - ASCII CR, Hex \$0D, or keyboard Enter - as an 'End-of-command' character.

Responses from the 232-Amp+ begin with the ASCII < (less than symbol) as an 'Attention' character and end with a carriage return followed by line feed an ASCII LF or Hex \$0A as 'End-of-command' characters.

A carriage return is required at the end of each command and is assumed in all examples.

Command String Structure

[Attention] (Unit#) [Command] (Parameters) [Return]

Attention	Single character (>) starts the string
Unit#	The Unit# is expressed as an ASCII 0-9 when used in multiple tuner applications. To address all units, use a Unit # of 0 (Zero) No unit number will default to Unit#1
Command	A two-character command
Parameters	Added attributes to some commands
Return	A carriage return ends the command string, you may use ASCII CR, Hex \$0D, or keyboard 'Enter' in programming. For simplicity, the programming examples in the manual will not show the 'CR' – so remember, you'll need to add it in your control code.

Command and Status Response

Commands can be sent back to back at any time without any delay. To allow for rapid, multiple commands, status responses are intentionally delayed by about 125mS, sending the most current status in response to control commands or user actions.

Control Commands

Code	Function	Operation
	Level	You can skip leading zeros on values – so 5 can be 5, 05 or 005
VL=	Stereo input volume	0 (mute) to 63 (full)
VM	Stereo input mute on	Mutes input
VX	Stereo input mute off	Restores volume to previous level
VU	Ramp stereo volume up	Starts volume ramping up
VD	Ramp stereo volume down	Starts volume ramping down
VV	Stop stereo volume ramp	Stops volume ramping
VT	Toggle stereo Volume Mute	Alternates audio mute on and off
VG=	Amplifier Gain	Sets gain level Sent alone returns amp gain status 0=20 dB (default) 1=26 dB 2=32 dB 3=36 dB
Inputs	Volume Parameter “Bump”	Send input volume parameter with 255 will bump value to next step. Send parameter with 254 will bump value down one step This allows wall panels that can’t send a volume ramp from press and a ramp stop from release to just bump the level up with each button press.
V0=	Stereo Input	Stated with <parameter>,<value> V0 alone will return status for Stereo (xx)=Default setting 1=Volume level 1-63 (40) 2=Max gain level 0-63 (0-63, also acts as mute on/off) 3=Min gain level 0-63 Fixed at 0, variable in future 4=Power On Threshold 0-63 (4) 5=Power On Hold delay 0-99 seconds (99) 0=Always On Ex: ‘>V0=1,30’
V1=	Mono 1	Stated with <parameter>,<value> V1 alone will return status for Input 1 Input 1 always has priority for ducking (xx)=Default setting 1=Volume level 0-63 (40) 2=Max gain level 0-63 (0-63, also acts as mute on/off) 3=Min gain level 0-63 (Fixed at 0), variable in future 4=Gating threshold level 1-63 (10) 5=Gating hold time 0-50 in 0.1 seconds (15) 00=Ducking off, acts as mixed input 6=Ducking level for the stereo input 0-63 (10) Example: ‘>V1=1,20 V1=4,03 V1=5,10 V1=6,05’
V2=	Mono 2	Stated with <parameter>,<value> V2 alone will return status for Input 2 (xx)=Default setting 1=Volume level 0-63 (40) 2=Max gain level 0-63 (0-63, also acts as mute on/off) 3=Min gain level 0-63 (Fixed at 0), variable in future 4=Gating threshold level 1-63 (10) 5=Gating hold time 0-50 in 0.1 seconds (15) 00=Ducking off, acts as mixed input 6=Ducking level for the stereo input 0-63 (10)
SV	Amp Status	Returns Amp/Stereo status string

RS-232 Commands

Terminal Communication Commands

EF	Echo Off	Characters received will not be re-transmitted (power up default).
EN	Echo On	Characters received will be re-transmitted. Example: '>EN' Characters received will be re-transmitted.
ID	Product ID	Returns the product model number and software version.
Z!	Zap	Reconfigures unit for all factory default settings: Unit #1 VG: 0 V0: 40,63,0,4,99,0 V1: 40,63,0,10,15,10 V2: 40,63,0,10,15,10

RS-232 Command Hints and Tips

You can control a 232-Amp+ and a 232-series tuner from a single RS-232 port by daisy-chaining RS-232 between the Amp and Tuner. Set the Tuner to ID 2, the Amp will always be unit 1.

Example: '>1VM2P0' Sets the 232-Amp+ to mute, and the tuner to Off.

The carriage return line feed at the end of each 232-Amp+ response allows for easy monitoring of responses with an ASCII terminal program. You may use ASCII CR, Hex \$0D, or keyboard 'Enter' in programming.

You don't have to use the '=' character between the command and parameter – the string works either way.

Gating and Volume

If you want the 232-Amp+ to act as a straight mixer, set Mono 1 and Mono 2 Gate Threshold (4) and Gate Hold (5) to zero (00). Note that both need to be turned off, the 232-Amp+ works best as either a fully gated smart mixer or as a standard mixer, not both.

Usually, gating works well at the default settings, but feel free to adjust the Gate Threshold (4) and Gate Hold (5) to work best with your application.

Try testing the system with the 232-Amp+ set higher than the default 20 dB gain (VG command). There are slight changes in gating performance at the highest levels, but usually 26 dB offers a good blend of volume and performance.

Cloning Amplifiers

If you are installing a number of units in the same facility, you can clone your settings using HyperTerminal, Tera Term, or other Terminal app. Most allow you to send a text file instead of typing all the settings. Type in the series of commands in Notepad or other text editor such as:

```
>VG=1  
>VL=60  
>V0=5,00  
>V1=1,60  
>V21,60 (if you want to skip the '=' sign)
```

Once you've refined all the settings, just sent the file to the other 232-AMPs in the site. After that, the installer can use a screwdriver and the DIP switches to tweak volume levels for the room.

Response Strings

Typical: [Attention] [Unit#] [data ...data] [cr] [lf]

232-Amp+ status response strings contain ASCII characters similar to those used for the same functions in command strings. An ASCII 'carriage return' and 'line feed' follow each response string. Functions shown as N/A are not applicable; characters will appear in status strings as lower-case x.

Input 0 (Stereo) Status Response String (V0):

Start	Unit	CMD		Volume	Max	Min	On	Hold	Power	
	1			0-63 2 digits	0-63 2 digits	0-63 2 digits	0-63 2 digits	0-99 2 digits	Preset 2 digits	
<	1	V0	XXX	63	63	00	03	20	20	XXXXXX

Input 1 Status Response String (V1):

Start	Unit	CMD		Volume	Max	Min	Gate	Hold	Duck	
	1			0-63 2 digits	0-63 2 digits	0-63 2 digits	0-63 2 digits	0-50 2 digits	0-63 2 digits	
<	1	V1	XXX	63	63	00	10	15	03	XXXXXX

Input 2 Status Response String (V2):

Start	Unit	CMD		Volume	Max	Min	Gate	Hold	Duck	
	1			0-63 2 digits	0-63 2 digits	0-63 2 digits	0-63 2 digits	0-50 2 digits	0-63 2 digits	
<	1	V2	XXX	63	63	00	10	15	03	XXXXXX

Amp Status Response String (SV):

Start	Unit	CMD	Power	Volume	Mute	Stereo
	1		U=On M=Off	0-63 2 digits	U=Off M=On	
<	1	V	M	63	U	S

Amp Gain Response String (VG):

Start	Unit	CMD	Gain	
	1		0-3 1 digit	
<	1	VG	1	XXXX

RS-232 Cable Connections


Single 232-Amp+

RS-232 Wiring – Amp

RS-232 Control Port	<u>5 GND</u>	<u>GND 5</u>	Captive Screw Terminal
	<u>2 RXD</u>	<u>TXD 3</u>	
	<u>3 TXD</u>	<u>RXD 4</u>	

RS-232 wiring for control or programming should only use pins 2, 3, 5. Cables with all pins wired can lock out front-panel programming and data communication (Pins 4 and 9 are inputs).

Rack Mounting



RK3 AV Tool Rack Kit

Install 232-Amp+ into the center of the RK3 rack mount using included 4-40 ¼" screws

Limited Warranty and Disclaimer

Warranty: Three (3) year limited warranty on all parts and labor for Contemporary Research manufactured products from the day of purchase by authorized dealer. Manufactured products are warranted against defects in materials and workmanship. If Contemporary Research receives notice of such defects during the warranty period, Contemporary Research will repair or replace, at its option, products that prove to be defective.

Exclusions: The above warranty shall not apply to defects resulting from improper or inadequate maintenance by the customer, customers applied software or interfacing, unauthorized modifications or misuse, mishandling, operation outside the normal environmental specifications for the product, use of the incorrect, modified or extended power supply, or improper site operation and maintenance. *Please note Contemporary Research SSV-DX Display Express PC product carries a six month limited warranty.*

Limited Warranty and Disclaimer

Contemporary Research Corporation (CR) warrants this product to be free from defects in material and workmanship under normal use for a period of two years from the date of purchase from CR. Should such a defect occur CR will repair or replace, at their option, the defective product at no cost for parts or labor.

This warranty extends to product purchased directly from CR or an Authorized CR Dealer. Consumers should inquire from selling dealer as to the nature and extent of the dealer's warranty, if any.

All warranty claims must be shipped pre-paid to the factory. Call or fax to obtain a Return Material Authorization (RMA) number.

CR is not liable for any damages caused by any of its products or for the failure of any products to perform, including any lost profits, lost savings, incidental damages, or consequential damages. CR is not responsible for any claim made by a third party or made for you by a third party. This limitation of liability applies whether damages are sought, or a claim is made, under this warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation of liability cannot be waived or amended by any person. This limitation of liability will be effective even if CR or an authorized representative of CR has been advised of the possibility of any such damages.

Some states do not allow a limitation of how long an implied warranty lasts. Some states do not allow the limitation or exclusion of incidental or consequential damages for consumer products. In such states, the limitation or exclusion of the Limited Warranty may not apply to you. This Limited Warranty gives you specific legal rights. You may also have other rights that may vary from state to state. You are advised to consult applicable state laws for a full determination of your rights.

Except as expressly set forth in this Limited Warranty, CR makes no other warranties, expressed or implied, including any implied warranties of merchantability or fitness for a particular purpose. CR expressly disclaims all warranties not stated in this Limited Warranty. Any implied warranties that may be imposed by law are limited to the terms of this Limited Warranty.